126.2931.30:- 23/04/10 13:57 Página 1

Thinking of you

Electrolux

Manual de uso
User manual

Lavadora
Washing machine

EWF107410W / EWF127410W

Downloaded From WashingMachine-Manual.com Manuals

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 29

Contents

Safety information.....30
Product description 32
Control panel.....33
Use.....34
Washing hints.....40
Washing programme 43
Care and cleaning 44
Something not working.....47
Techical data 50
Consumption values.....51
Installation 52
Environment concerns.....54
Guarantee conditions 55
Customer service centres.....56

The following symbols are used in this manual:

Important information concerning your personal safety and information on how to avoid damaging the appliance.

General information and tips

Environmental information

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 30

Safety Information

In the interest of your safety and to ensure the correct use, before installing and first using the appliance, read this user manual carefully, including its hints and warnings. To avoid unnecessary mistakes and accidents, it is important to ensure that all people using the appliance are thoroughly familiar with its operation and safety features. Save these instructions and make sure that they remain with the appliance if it is moved or sold, so that everyone using it through its life will be properly informed on appliance use and safety.

General safety

- It is dangerous to alter the specifications or attempt to modify this product in any way.
- During high temperature wash programmes the door glass may get hot. Do not touch it!
- Make sure that small pets do not climb into the drum. To avoid this, please check into the drum before using.
- Any objects such as coins, safety pins, nails, screws, stones or any other hard, sharp material can cause extensive damage and must not be placed into the machine.
- Only use the advised quantities of fabric softener and detergent. Damage to the fabric can ensue if you over-fill. Refer to the manufacturer's recommendations of quantities.
- Wash small items such as socks, laces, washable belts etc in a washing bag or pillow case as it is possible for such items to slip down between the tub and the inner drum.
- Do not use your washing machine to wash articles with whalebones, material without hems or torn material.
- Always unplug the appliance and turn off the water supply after use, clean and maintenance.
- Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Centre. Always insist on genuine spare parts.

Installation

- This appliance is heavy. Care should be taken when moving it.
- When unpacking the appliance, check that it is not damaged. If in doubt, do not use it and contact the Service Centre.
- All packing and transit bolts must be removed before use. Serious damage can occur to the product and to property if this is not adhered to. See relevant section in the user manual.
- After having installed the appliance, check that it is not standing on the inlet and drain hose and the worktop is not pressing the electrical supply cable.
- If the machine is situated on a carpeted floor, please adjust the feet in order to allow air to circulate freely
- Always be sure, that there is no water leakage from hoses and their connections after the installation.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 31

- If the appliance is installed in a location subject to frost, please read the "**dangers of freezing**"chapter.
- Any plumbing work required to install this appliance should be carried out by a qualified plumber or competent person.
- Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.

Use

- This appliance is designed for domestic use. It must not be used for purposes other than those for which it was designed.
- Only wash fabrics which are designed to be machine washed. Follow the instructions on each garment label.
- Do not overload the appliance. See the relevant section in the user manual.
- Before washing, ensure that all pockets are empty and buttons and zips are fastened. Avoid washing frayed or torn articles and treat stains such as paint, ink, rust, and grass before washing. Underwired bras must NOT be machine washed.
- Garments which have been in contact with volatile petroleum products should not be machine washed. If volatile cleaning fluids are used, care should be taken to ensure that the fluid is removed from the garment before placing in the machine.
- Never pull the power supply cable to remove the plug from the socket; always take hold of the plug itself.
- Never use the washing machine if the power supply cable, the control panel, the working surface or the base are damaged so that the inside of the washing machine is accessible.

Child safety

- This washing machine is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.
- The packaging components (e.g. plastic film, polystyrene) can be dangerous to children - danger of suffocation! Keep them out of children's reach
- Keep all detergents in a safe place out of children's reach.
- Make sure that children or pets do not climb into the drum. To avoid this the machine incorporates special feature.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 32

Product description

Your new appliance meets all modern requirements for effective treatment of laundry with low water, energy and detergent consumption.
The ECO valve system allows total use of detergent and reduces water consumption so saving energy.

1 Detergent dispenser drawer
2 Control panel
3 Door opening handle
4 Drain pump
5 Adjustable feet



Detergent dispenser drawer

I Prewash
II Wash
Fabric Softener



Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 33

Control panel



1. **Programme selector dial**
2. **Temperature button**
3. **Spin reduction button**
4. **Prewash button**
5. **AquaCare button**
6. **Delay Start button**
7. **Start/Pause button**
8. **Door**
9. **Time Manager buttons**

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 34

Use

First Use

- Ensure that the electrical and water connections comply with the installation instructions.
- Remove the polystyrene block and any material from the drum.
- Pour 2 litres of water into the main wash compartment II of the detergent drawer in order to activate the ECO valve. Then run a cotton cycle at 90°C, without any laundry in the machine, to remove any manufacturing residue from the drum and tub. Pour 1/2 a measure of detergent into the dispenser drawer and start the machine.

Daily Use

Load the laundry

Open the door by carefully pulling the door handle outwards. Place the laundry in the drum, one item at a time, shaking them out as much as possible. Close the door.



Measure out the detergent and the fabric softener

Pull out the dispenser drawer until it stops. Measure out the amount of detergent required, pour it into the main wash compartment II and, if you wish to carry out the "**prewash**" phase, pour it into the compartment marked I.





If required, pour fabric softener into the compartment marked ❀ (the amount used must not exceed the "MAX" mark in the drawer). Close the drawer gently.

Select the required programme

Turn the programme selector dial to the required programme.
The Start/Pause light starts to flash and the Display shows the duration of the selected programme.

The selector dial is divided into following sections:

Cottons
Synthetics
Delicates
Special programmes: Rinses, Drain, Spin.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 35

The selector dial can be turned either clockwise or anticlockwise. Position **O** to Reset programme/ Switching OFF of the machine.

At the end of the programme the selector dial must be turned to position O, to switch the machine off.

Attention!
If you turn the programme selector dial to another programme when the machine is working, the red Start/Pause pilot light will flash 3 times to indicate a wrong selection. The machine will not perform the new selected programme.

Programme Option buttons

Depending on the programme, different functions can be combined. These must be selected after choosing the desired programme and before depressing the Start/Pause button.
When these buttons are pressed, the corresponding pilot lights come on.
When they are pressed again, the pilot lights go out.

Select the temperature



Press this button repeatedly to increase or decrease the temperature, if you want your laundry to be washed at a temperature different from the one proposed by the washing machine.

Maximum temperatures are 90°C for cottons, 60°C for synthetics, 40°C for delicates, wool, fabrics to be handwashed and lingerie, 30°C for silk, ✳ while corresponds to cold wash.

Select the spin speed or No Spin or Rinse Hold option



Press the Spin button repeatedly to change the spin speed, if you want your laundry to be spun at a speed different from the one proposed by the washing machine.

The relevant light will light up.

Maximum speeds are:

Mod.EWF 127410 W:
- for cotton: 1200 rpm;
- for synthetics, wool and handwash: 900 rpm;
- for delicate fabrics: 700 rpm.

Mod. EWF 107410 W:
- for cotton: 1000 rpm;
- for synthetics, wool and handwash: 900 rpm;
- for delicate fabrics: 700 rpm.

Night Cycle : by selecting this option, the machine will not drain the water of the last rinse, so as not to wrinkle the laundry.
As all spinning phases are suppressed, this washing cycle is very noiseless and it can be selectionned at night or in times with a more economical power rate.
On cotton, synthetic, delicates and silk programmes the rinses will be performed with more water.
When the programme has finished, the display shows a 0.00 flashing, the pilot light (Door) is on, the Start/Pause light is off and the door is locked to indicate that the water must be emptied out.

Rinse Hold : by selecting this option the water of the last rinse is not emptied out to prevent the fabrics from creasing.
When the programme has finished the

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 36

pilot light (Door) is on, the Start/Pause light is off and the door is blocked to indicate that the water must be emptied out.

To empty out the water:

turn the programme selector dial to "**O**"
select the (Drain), (Spin) programme
reduce the spin speed if needed, by means of the relevant button
depress Start/Pause button

Select the Prewash (Prelavado) option

Select this option if you wish your laundry to be prewashed at 30ºC before the main wash.
The prewash ends with a short spin in programmes for Cotton and Synthetic fabrics, whereas in the programmes for Delicates fabrics the water is only drained.

Select the AquaCare option

This button can be selected with all programmes except the wool and hand wash programmes. The machine performs some additional rinses.
This option is recommended for people who are allergic to detergents, and in areas where the water is very soft.

Display

The display shows the following information:

Duration of the selected programme

After selecting a programme, the duration is displayed in hours and minutes (for example ***2.05***).

The duration is calculated automatically on the basis of the maximum recommended load for each type of fabric.

After the programme has started, the time remaining is updated every minute.

Incorrect option selection

If an option which is not compatible with the set wash programme is selected, the message Err is displayed for about 2 seconds and the integrated red Start/Pause light start flashing.



Alarm codes

In the event of operating problems, some alarm codes can be displayed, for example ***E20*** (see paragraph "Something not working").

End of programme

When the programme has finished a flashing zero is displayed.



Heating phase

During the washing cycle the display shows a temperature icon to indicate that the appliance has started the heating phase of the water in the tub.



Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 37

Select the Start/Pause

To start the selected programme, press the **“Start/Pause”** button; the green pilot light stops flashing.

The **“door”** light is on to indicate that the appliance starts operating and the door is locked.

To interrupt a programme which is running, depress the **“Start/Pause”** button: the green pilot light starts to flash.

To restart the programme from the point at which it was interrupted, **press** the “Start/Pause” **button again**.

If you have chosen a delayed start, the machine will begin the countdown.

If an incorrect option is selected, an integrated red pilot light of the “Start/Pause” button flashes for 3 times.

Select the Delay start

Before you start the programme, if you wish to delay the start, press the Delay Start button repeatedly, to select the desired delay. The selected delay time value (up to 20 hours) will appear on the display for about 3 seconds, then the duration of the programme will appear again.

You must select this option after you have set the programme and before you press the Start/Pause button.

You can cancel the delay time at any moment, before you press the Start/Pause button.

The wash programme can be delayed from 30 min - 60 min - 90 min, 2 hours and then by 1 hour up to a maximum of 20 hours by means of this button.

Selecting the delayed start.

- Select the programme and the required options.
- Select the delay start.
- Depress “Start/Pause” button: the machine starts its hourly countdown.

The programme will start after the selected delay has expired.

Cancelling the delayed start

- Depress “Start/Pause” button.
- Depress “Start/Pause” button more times until the symbol *0′* is displayed.
- Depress “Start/Pause” button again.

The Delay Start can not be selected with **Spin** , and **Drain** programmes.

Select the Time Manager buttons

By pressing these buttons repeteadly, the duration of the washing cycle can be increased or decreased. The soil level icon will appear on the display to indicate the chosen degree of soil. This option is available only with Cotton, Synthetic and Delicate programmes.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 16:39 Página 38

Soil Level	Icon	Type of fabric
Intensive		For heavy soiled items
Normal		For normal soiled items
Daily		For daily soiled items
Light		For slightly soiled items
Quick		For very slightly soiled items
SuperQuick (*)		For items used or worn for a short time
Refresh(*)	(**)	For refreshing items only
Super Refresh (*)	(**)	For refreshing a very few intems only

(*)Max. load for cotton: 3,5 kg
Max. load for syntehtic and delicate: 2,5 kg.
(**) When you select this option the relevant icon appears just for a while and then it disappears immediately.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 39

Altering an option or a running programme

It is possible to change any option before the programme carries it out. Before you make any change, you must pause the washing machine by pressing the **"Start/Pause"** button.

Changing a running programme is possible **only by resetting it**. Turn the programme selector dial to **"O"** and then to the new programme position. The washing water in the tub will not emptied out. Start the new programme by depressing the **"start pause"** button again.

Interrupting a programme

Depress the **"start pause"** button to interrupt a programme which is running, the corresponding light starts to flash. Depress the button again to restart the programme.

Cancelling a programme

Turn the selector dial to **"O"** to cancel a programme which is running. Now you can select a new programme.

Opening the door after the programme has started

First set the machine to pause by pressing the **"Start/Pause"** button.
If the **"door"** light flashes and after 2 minutes goes off, the door can be opened.
If the **"door"** light does not switch off, this means that the machine is already heating, that the water level is above the bottom edge of the door or that the drum is turning.
In this case the door can not be opened.

If you cannot open the door but you need to open it you have to switch the machine off by turning the selector dial to **"O"**. After about 2 minutes the door can be opened **(pay attention to the water level and temperature!)**.

At the end of the programme

The machine stops automatically.

If the **"rinse hold"** option has been selected, the phase lights **"end"** and **"door"** illuminate, the **"Start/Pause"** light goes off and the door remains locked to indicate that the water must be emptied out before opening the door.

To empty out the water please read the steps on the Rinse Hold option paragraph.

Turn the programme selector dial to **"O"** to switch the machine off. Remove the laundry from the drum and carefully check that the drum is empty.

If you do not intend to carry out another wash, close the water tap. Leave the door open to prevent the formation of mildew and unpleasant smells.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 40

Washing hints

Sorting the laundry

Follow the wash code symbols on each garment label and the manufacturer's washing instructions. Sort the laundry as follows: whites, coloureds, synthetics, delicates, woollens.

Temperatures

90°	for normally soiled white cottons and linen (e.g. tea cloths, towels, tablecloths, sheets...)
60°	for normally soiled, colour fast garments (e.g. shirts, night dresses, pyjamas....) in linen, cotton or synthetic fibres and for lightly soiled white cotton (e.g. underwear).
30°-40°	for delicate items (e.g. net curtains), mixed laundry including synthetic fibres and woollens bearing the label «pure new wool, machine washable, non-shrink».

Before loading the laundry

Never wash whites and coloureds together. Whites may lose their "whiteness" in the wash.

New coloured items may run in the first wash; they should therefore be washed separately the first time.

Make sure that no metal objects are left in the laundry (e.g. hair clips, safety pins, pins).

Button up pillowcases, close zip fasteners, hooks and poppers. Tie any belts or long tapes.

Remove persistent stains before washing. Rub particularly soiled areas with a special detergent or detergent paste.

Treat curtains with special care. Remove hooks or tie them up in a bag or net.

Maximum loads

Recommended loads are indicated in the programme charts.

General rules:

Cotton, linen: drum full but not too tightly packed;

Synthetics: drum no more than half full;

Delicate fabrics and woollens: drum no more than one third full.

Washing a maximum load makes the most efficient use of water and energy.

For heavily soiled laundry, reduce the load size.

Laundry weights

The following weights are indicative:

bathrobe	1200g
napkin, tea cloth, lady's brief, blouse	100g
quilt cover	700g
sheet	500g
pillow case, towelling towel, night dress	200g
table cloth	250g
man's shirt	200g
man's pyjamas	600g
men's underpanths	100g

Removing stains

Stubborn stains may not be removed by just water and detergent. It is therefore advisable to treat them prior to washing.

Blood: treat fresh stains with cold water. For dried stains, soak overnight in water with a special detergent then rub in the soap and water.

Mould stains: treat with bleach, rinse well (whites and fast coloureds only).

Ink: depending on the type of ink, moisten the fabric first with acetone (*), then with acetic acid; treat any residual marks on white fabrics with bleach and then rinse thoroughly.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 41

Oil based paint: moisten with benzine stain remover, lay the garment on a soft cloth and dab the stain; treat several times.

Dried grease stains: moisten with turpentine, lay the garment on a soft surface and dab the stain with the fingertips and a cotton cloth.

Rust: oxalic acid dissolved in hot water or a rust removing product used cold. Be careful with rust stains which are not recent since the cellulose structure will already have been damaged and the fabric tends to hole.

Grass: soap lightly and treat with bleach (whites and fast coloureds only).

Ball point pen and glue: moisten with acetone (*), lay the garment on a soft cloth and dab the stain.

Lipstick: moisten with acetone as above, then treat stains with methylated spirits. Remove any residual marks from white fabrics with bleach.

Red wine: soak in water and detergent, rinse and treat with acetic or citric acid, then rinse. Treat any residual marks with bleach.

Tar stains: first treat with stain remover, methylated spirits or benzine, then rub with detergent paste.

(*) do not use acetone on artificial silk.

Detergents and additives

Good washing results also depend on the choice of detergent and use of the correct quantities to avoid waste and protect the environment. Although biodegradable, detergents contain substances which, in large quantities, can upset the delicate balance of nature.

The choice of detergent will depend on the type of fabric (delicates, woollens, cottons, etc.), the colour, washing temperature and degree of soiling.

All commonly available washing machine detergents may be used in this appliance:

- powder detergents for all types of fabric,
- powder detergents for delicate fabrics (60°C max) and woollens,
- liquid detergents, preferably for low temperature wash programmes (60°C max) for all types of fabric, or special for woollens only.

The detergent and any additives must be placed in the appropriate compartments of the dispenser drawer before starting the wash programme.

If using concentrated powder or liquid detergents, a programme **without** prewash must be selected.

Pour liquid detergent into the dispenser drawer compartment marked II **just before** starting the programme.

Any fabric softener or starching additives must be poured into the compartment marked ❀ before starting the wash programme.

Follow the product manufacturer's recommendations on quantities to use and **do not exceed the «MAX» mark in the detergent dispenser drawer.**

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 42

Quantity of detergent to be used

The type and quantity of detergent will depend on the type of fabric, load size, degree of soiling and hardness of the water used.

Water hardness is classified in so-called “degrees” of hardness. Information on hardness of the water in your area can be obtained from the relevant water supply company, or from your local authority.

Follow the product manufacturers’ instructions on quantities to use.

Use less detergent if:

- you are washing a small load,
- the laundry is lightly soiled,
- large amounts of foam form during washing.

Degrees of water hardness			
Level	Characteristic	Degrees	
		German °dH	French °T.H.
1	soft	0-7	0-15
2	medium	8-14	16-25
3	hard	15-21	26-37
4	very hard	> 21	> 37

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 43

Washing programmes

Programme / Temperature	Type of laundry	Options
Cotton 90°-	White and coloureds cotton: e.g. sheets, tablecloths, household, linen.	Spin Red.,
Synthetic 60°-	Synthetic or mixed fabrics, underwear, coloured garments, non-shrink shirts, blouses.	
Delicate 40°-	Delicate fabrics, for example curtains.	
Wool 40°-	Washing probramme for machine washable wool as well as for hand washable woollens and delicate fabrics.	Spin Red.,
Silk 30°-	Special programme for delicate fabrics.	
Handwash 40°-	Washing probramme for machine washable wool as well as for hand washable woollens and delicate fabrics.	
Soak 30°	Select this programme if you wish your landry to be prewashed at 30ºC before main wash.	
Rinse	Sperate rinse cycle for hand washed items of all fabric.	Spin Red.,
Drain	For emtying out the last rinse water in programmes with the Rinse Hold option.	
Spin	Separate spin for all fabric	
Cotton Eco 90º- 40°	This programme can be selected for slightly or normally soiled cotton items. This allows to obtain a good washing effieciency by saving energy.	Spin Red.,
Easy iron 60°-	Selecting this programme the laundry is fently washed and spun to avoid any creasing. In this way ironing is easier.	
Jeans 60°-	With this programme it is possible to wash items like pants, shirts o jackets in Jeans and also jersey realized with hitech materials.	
Blanket 40º- 30°	Washing programme for a single synthetic blanket, bedspread, etc.	
O	For cancelling the wash programme which is running and for switching the machine off.	

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 44

Care and cleaning

You must DISCONNECT the appliance from the electricity supply, before you can carry out any cleaning or maintenance work.

Descaling

The water we use normally contains lime. It is a good idea to periodically use a water softening powder in the machine. Do this separately from any laundry washing, and according to the softening powder manufacturer's instructions. This will help to prevent the formation of lime deposits.

After each wash

Leave the door open for a while. This helps to prevent mould and stagnant smells forming inside the appliance. Keeping the door open after a wash will also help to preserve the door seal.

Maintenance Wash

With the use of low temperature washes it is possible to get a build up of residues inside the drum.
We recommend that a maintenance wash be performed on a regular basis.

To run a maintenance wash:
- The drum should be empty of laundry.
- Select the hottest cotton wash programme.
- Use a normal measure of detergent, must be a powder with biological properties.

External cleaning

Clean the exterior cabinet of the appliance with soap and water only, and then dry thoroughly.

Cleaning the dispenser drawer

The washing powder and additive dispenser drawer should be cleaned regularly.
Remove the drawer by pressing the catch downwards and by pulling it out. Flush it out under a tap, to remove any traces of accumulated powder.



To aid cleaning, the top part of the additive compartment should be removed.

Cleaning the drawer recess

Having removed the drawer, use a small brush to clean the recess, ensuring that all washing powder residue is removed from the upper and lower part of the recess.
Replace the drawer and run the rinse programme without any clothes in the drum.



Cleaning the pump

The pump should be inspected if
- the machine does not empty and/or spin
- the machine makes an unusual noise during draining due to objects such as safety pins, coins etc. blocking the pump.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 45

Proceed as follows:
- Disconnect the appliance.
- If necessary wait until the water has cooled down.
- Open the pump door.





- Place a containfer close to the pump to collect any spillage.
- When no more water comes out, unscrew the pump cover and remove it. Always keep a rag nearby to dry up spillage of water when removing the cover.





- Remove any objects from the pump impeller by rotating it.
- Screw the pump cover fully in.
- Close the pump door.

Warning!

When the appliance is in use and depending on the programme selected there can be hot water in the pump.Never remove the pump cover during a wash cycle, always wait until the appliance has finished the cycle, and is empty. When replacing the cover, ensure it is securely retightened so as to stop leaks and young children being able to remove it.

Cleaning the water inlet filter

If your water is very hard or contains traces of lime deposit, the water inlet filter may become clogged.

It is therefore a good idea to clean it from time to time.

Turn off the water tap. Unscrew the water inlet hose. Clean the filter using a hard bristle brush. Tighten up the inlet hose.



The dangers of freezing

If the machine is exposed to temperatures below 0°C, certain precautions should be taken.
- Turn off the water tap.
- Unscrew the inlet hose.
- Place the end of the inlet hose in a bowl placed on the floor and let water drain out.
- Screw the water inlet hose back on.
- When you intend to start the machine up again, make sure that the room temperature is above 0°C.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 46

Important!

Every time you drain the water through the emergency emptying hose you must pour 2 litres of water into the main wash compartment of the detergent drawer and then run the drain programme. This will activate the ECO VALVE device avoiding that part of the detergent remains unused at next washing.

Emergency emptying out

If the water is not discharged, proceed as follows to empty out the machine:

- pull out the plug from the power socket;
- close the water tap;
- if necessary, wait until the water has cooled down;
- open the pump door;
- place a bowl on the floor. The water should drain by gravity into the bowl. When the bowl is full, put the cap back on the hose. Empty the bowl. Repeat the procedure until water stops flowing out;
- clean the pump if necessary as previously described;
- screw the pump cover again and close the door.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 47

Something not working

Certain problems are due to lack of simple maintenance or oversights, which can be solved easily without calling out an engineer. Before contacting your local Service Centre, please carry out the checks listed below.

During machine operation it is possible that the red Start/Pause pilot light flashes and one of the following alarm codes appears on the display to indicate that the machine is not working:

- **E10:** problem with the water supply
- **E20:** problem with water draining
- **E40:** door open.

Once the problem has been eliminated, press the **Start/Pause** button to restart the programme. If after all checks, the problem persists, contact your local Service Centre.

Malfunction	Possible cause	Solution
The washing machine does not start:	• The door has not been closed. **E40**.	• Close firmly the door.
	• The plug is not properly inserted in the power socket.	• Insert the plug into the power socket.
	• There is no power at the socket.	• Please check your domestic electrical installation.
	• The main fuse has blown.	• Replace the fuse.
	• The selector dial is not correctly positioned and the Start/Pause button has not been depressed.	• Please turn the selector dial and press the Start/Pause button again.
	• The delay start has been selected.	• If the laundry are to be washed immediately, cancel the delay start.
The machine does not fill:	• The water tap is closed. **E10**	• Open the water tap.
	• The inlet hose is squashed or kinked. **E10**	• Check the inlet hose connection.
	• The filter in the inlet hose is blocked. **E10**	• Clean the water inlet hose filter.
	• The door is not properly closed. **E40**	• Close firmly the door.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 48

Malfunction	Possible cause	Solution
The machine fills then empties immediately:	• The end of the drain hose is too low.	• Refer to relevant paragraph in “water drainage” section.
The machine does not empty and/or does not spin:	• The drain hose is squashed or kinked. **E20** • The drain pump is clogged. **E20** • The the option ▭ or ◔ has been selected. • The laundry is not evenly distributed in the drum.	• Check the drain hose connection. • Clean the drain pump. • Disable the option ▭ or ◔ • Redistribute the laundry.
There is water on the floor:	• Too much detergent or unsuitable detergent (creates too much foam) has been used. • Check whether there are any leaks from one of the inlet hose fittings. It is not always easy to see this as the water runs down the hose; check to see if it is damp. • The drain hose is damaged.	• Reduce the detergent quantity or use another one. • Check the water inlet hose connection. • Change it with a new one.
Unsatisfactory washing results:	• Too little detergent or unsuitable detergent has been used. • Stubborn stains have not been treated prior to washing. • The correct temperature was not selected. • Excessive laundry load.	• Increase the detergent quantity or use another one. • Use commercial products to treat the stubborn stains. • Check if you have selected the correct temperature. • Introduce into the drum less laundry.
The door will not open:	• The programme is still running. • The door lock has not been released. • There is water in the drum.	• Wait the end of washing cycle. • Wait about 2 minute. • Select drain or spin programme to empty out the water.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 49

Malfunction	Possible cause	Solution
The machine vibrates or is noisy:	• The transit bolts and packing have not been removed. • The support feet have not been adjusted. • The laundry is not evenly distributed in the drum. • Maybe there is very little laundry in the drum.	• Check the correct installation of the appliance. • Check the correct levelling of the appliance. • Redistribute the laundry. • Load more laundry.
Spinning starts late or the machine does not spin:	• The electronic unbalance detection device has cut in because the laundry is not evenly distributed in the drum. The laundry is redistributed by reverse rotation of the drum. This may happen several times before the unbalance disappears and normal spinning can resume. If, after 10 minutes, the laundry is still not evenly distributed in the drum, the machine will not spin. In this case, redistribute the load manually and select the spin programme.	• Redistribute the laundry.
The machine makes an unusual noise	• The machine is fitted with a type of motor which makes an unusual noise compared with other traditional motors. This new motor ensures a softer start and more even distribution of the laundry in the drum when spinning, as well as increased stability of the machine.	
No water is visible in the drum	• Machines based on modern technology operate very economically using very little water without affecting performance.	

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 50

If you are unable to identify or solve the problem, contact our service centre. Before telephoning, make a note of the model, serial number and purchase date of your machine: the Service Centre will require this information.



Technical data

Dimensions	Width		60 cm
	Height		85 cm
	Depth		64 cm
Electrical connection Voltage - Overall power - Fuse	Information on the electrical connection is given on the rating plate on the inner edge of the appliance door		
Water supply pressure	Minimum		0,05 MPa
	Maximum		0,8 MPa
Maximum Load	Cotton		7 kg
	Synthetics		3 kg
	Delicates		3 kg
	Woollens and handwash		2 kg
Spin Speed	Maximum	Mod. EWF 127410 W	1200 rpm
		Mod. EWF 107410 W	1000 rpm

CE

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 51

Consumption values			
Programme	**Programme duration (in minutes)**	**Energy consumption (in kWh)**	**Water consumption (in litres)**
Cottons 90°	155	2.15	65
Cottons 60° Eco (*)	160	1.19	59
Cottons 60°	125	1.02	54
Cottons 40° Eco	125	0.85	49
Cottons 40°-30°-Cold	115	0.55	49
Synthetics 60°	75	0.45	51
Synthetics 40°-30°-Cold	70	0.23	51
Delicates 40°-30°	50	0.25	55
Handwash 30°-Cold	55	0.07	55
Rinse	45	0.02	48
Drain	2	—	—
Spin	10	—	—

(*) The “Cottons 60° and option Eco selected” is the reference programme for the data entered in the energy label, in compliance with EEC 92/75 standards.

The consumption data shown on this chart is to be considered purely indicative, as it may vary depending on the quantity and type of laundry, on the inlet water temperature and on the ambient temperature. It refers to the highest temperature for each wash programme.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 52

Installation

Transit security bars

Before starting the machine up, **the transport security bars must be removed** as follows:

You are advised to keep all the transport security bars. In case the appliance has to be transported again.





1. Unscrew and remove the three rear screws by means of a key.
2. Open the porthole and remove the polies thyrene block fitted on the door seal.





3. Place the machine in an upright position and remove the three plastic bolts.
4. Plug the 3 holes with the plastic plugs which you can find in the envelope containing the instruction booklet.

Hydraulic connection

There should be a COLD WATER tap near the washing machine with a screwing on connection pipe of 3/4 gas for the water supply, a sink, a wash basin or a drainage system in the wall.

Previously check if:

- it is not a hot water tap.
- the running water is clean. If not, run off a reasonable amount of water to flush out any debris that may have collected in the pipes.

Have the permanent drainage system in the wall checked by a plumber.



1. Carefully screw the pipe to the tap taking care not to damage the screwdrive and fix the nut well on to the end in order to avoid leaking.



2. If necessary turn the hose adequately by unscrewing the nut at the rear of the appliance. Now tighten the nut anew to avoid leaks. (Open the tap and assure that it does not leak and close it again.)

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 53



3. Place the discharging hose in a washbasin or sink with the aid of the bent piece delivered separately. The bent piece has to be entered into the tube's mouth in order to assure the support. Aforesaid piece allows the hose to be fixed to the wall by means of an opening on the upper part and that way the hose does not move and its falling is avoided.



IMPORTANT:

The distance from the floor to the highest part of the hose should be between 60 to 90 cm. (It is advised to be between 60 and 70 cm). The hose must not be bent nor twisted to avoid clogging. Should a prolongation of the discharging hose be unavoidable this must never surpass 1.5 m and must be of the same diameter as the original hose.

Make sure the hoses are not too tense.

Levelling

Level the appliance by loosening or tightening the feet. Once in the right position fix the feet by pushing the nuts against the base of the case. Accurate levelling will prevent vibration, noise and displacement of the appliance during operation.

Some vibration is inevitable, especially if placed on a wooden floor. Wooden floors are particularly susceptible to vibrations. If possible always place the appliance on a solid floor.



Electrical connection

This machine is designed to operate on a 230 V, single-phase, 50 Hz supply.

Check that your domestic electrical installation can take the maximum load required (2.1 kW), also taking into account any other appliances in use.

The applicable rules for electrical security require an adequate earthing. The plug of the appliance is provided with such a device.

The manufacturer declines any responsibility for damage or injury through failure to comply with the above safety precaution. Should the appliance power supply cable need to be replaced, this should be carried out by our Service Centre.

Please ensure that when the appliance is installed the power supply cable is easily accessible.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 54

Environment concerns

Packaging materials

The materials marked with the symbol ♺ are recyclable.

>PE<=polyethylene

>PS<=polystyrene

>PP<=polypropylene

This means that they can be recycled by disposing of them properly in appropriate collection containers.

Old machine

Use authorised disposal sites for your old appliance. Help to keep your country tidy!

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Ecological hints

To save water, energy and to help protect the environment, we recommend that you follow these tips:

- Normally soiled laundry may be washed without prewashing in order to save detergent, water and time (the environment is protected too!).
- The machine works more economically if it is fully loaded.
- With adequate pre-treatment, stains and limited soiling can be removed; the laundry can then be washed at a lower temperature.
- Measure out detergent according to the water hardness, the degree of soiling and the quantity of laundry being washed.

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 55

Standard guarantee conditions.

This appliance is guaranteed by Electrolux, in each of the countries listed We, Electrolux, undertake that if within 12 months of the date of the purchase this Electrolux appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our option repair or replace the same FREE OF CHARGE for labour, materials or carriage on condition that:

- The appliance has been correctly installed and used only on the electricity supply stated on the rating plate.
- The appliance has been used for normal domestic purposes only, and in accordance with the manufacturer's instructions.
- The appliance has not been serviced, maintained, repaired, taken apart or tampered with by any person not authorised by us.
- Electrolux Service Force Centre must undertake all service work under this guarantee
- Any appliance or defective part replaced shall become the Company's property.
- This guarantee is in addition to your statutory and other legal rights.
- Exclusions
- Damage or calls resulting from transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.
- Costs incurred for calls to put right an appliance which is improperly installed or calls to appliances outside the United Kingdom.
- Appliances found to be in use within a commercial environment, plus those which are subject to rental agreements.
- Products of Electrolux manufacturer that are not marketed by Electrolux Service and Spare Parts

In the event of your appliance requiring service, or if you wish to purchase spare parts, please contact your local Service Force Centre by telephoning
Your telephone call will be automatically routed to the Service Force Centre covering your postcode area.
For the address of your local Service Force Centre and further information about Service Force, please visit the website at www.electrolux.fr
Before calling out an engineer, please ensure you have read the details under the heading "What to do if..."
When you contact the Service Force Centre you will need to give the following details:
1. Your name, address and postcode.
2. Your telephone number.
3. Clear concise details of the fault.
4. The model and Serial number of the appliance (found on the rating plate).
5. The purchase date.

Please note a valid purchase receipt or guarantee documentation is required for in guarantee service calls.
Customer Care
For general enquiries concerning your Electrolux appliance, or for further information on Electrolux products please contact our Customer Care Department by letter or telephone at the address below or visit our website at www.electrolux.fr
(*) Calls may be recorded for training purposes

Downloaded From WashingMachine-Manual.com Manuals

126.2931.30:- 23/04/10 13:57 Página 56

Customer Service Centres

Should you need further assintance please contact your local Customer Service Centre

Centro de Asistencia Técnica

En caso de necesitar una mayor ayuda, por favor contacte con su Centro de Asistencia Técnica

www.electrolux.com

Belgique/België/Belgien	+32 2 363 04 44	Bergensesteenweg 719, 1502 Lembeek
Česká republika	+420 2 61 12 61 12	Budějovická 3, Praha 4, 140 21
Danmark	+45 70 11 74 00	Sjællandsgade 2, 7000 Fredericia
Deutschland	+49 180 32 26 622	Muggenhofer Str. 135, 90429 Nürnberg
Eesti	+37 2 66 50 030	Mustamäe tee 24, 10621 Tallinn
España	+34 902 11 63 88	Carretera M-300, Km. 29,900 Alcalá de Henares Madrid
France	www.electrolux.fr	
Great Britain	+44 8705 929 929	101 Oakley Road LUTON Beds LU4 9RJ
Hellas	+30 23 10 56 19 70	4, Limnou Str., 54627 Thessaloniki
Hrvatska	+38 51 63 23 338	Slavonska avenija 3, 10000 Zagreb
Ireland	+353 1 40 90 753	Longmile Road Dublin 12
Italia	+39 (0) 434 558500	C.so Lino Zanussi, 26 - 33080 Porcia (PN)
Latvija	+37 17 84 59 34	Kr. Barona iela 130/2, LV-1012, Riga
Lituania	+370 5 27 80 609	Verkiu 29, 09108 Vilnius, Lithuania
Luxembourg	+35 2 42 43 13 01	Rue de Bitbourg, 7, L-1273 Hamm
Magyarország	+36 1 252 1773	H-1142 Budapest XIV, Erzsébet királyné útja 87
Nederland	+31 17 24 68 300	Vennootsweg 1, 2404 CG - Alphen aan den Rijn
Norge	+47 81 5 30 222	Risløkkvn. 2 , 0508 Oslo
Österreich	+43 18 66 400	Herziggasse 9, 1230 Wien
Polska	+48 22 43 47 300	ul. Kolejowa 5/7, Warsaw
Portugal	+35 12 14 40 39 39	Quinta da Fonte - Edificio Gonçalves Zarco - Q35 -2774-518 Paço de Arcos
Romania	+40 21 44 42 581	B-dul Timisoara 90, S6, Bucharest
Schweiz - Suisse - Svizzera	+41 62 88 99 111	Industriestrasse 10, CH-5506 Mägenwil
Slovenija	+38 61 24 25 731	Tržaška 132, 1000 Ljubljana
Slovensko	+421 2 43 33 43 22	Electrolux Slovakia s.r.o., Electrolux Domáce spotrebiče SK, Seberíniho 1, 821 03 Bratislava
Suomi	+35 8 26 22 33 00	Konepajanranta 4, 28100 Pori
Sverige	+46 (0)771 76 76 76	Electrolux Service, S:t Göransgatan 143, S-105 45 Stockholm
Türkiye	+90 21 22 93 10 25	Tarlabaşı caddesi no : 35 Taksim Istanbul
Россия	+7 095 937 7837	129090 Москва, Олимпийский проспект, 16, БЦ "Олимпик"

Downloaded From WashingMachine-Manual.com Manuals

Downloaded From WashingMachine-Manual.com Manuals

Downloaded From WashingMachine-Manual.com Manuals

Downloaded From WashingMachine-Manual.com Manuals

www.electrolux.com

126.2931.30

Downloaded From WashingMachine-Manual.com Manuals